



Scan the QR code to get multilingual user manual.



Packing list



Smart Watch x1



Charging Cable x1



User Manual x1

Specifications

Product model: C1 PLUS
 Waterproof rating: IP68
 Sensor: 3-axis G-sensor
 Battery capacity: 270mAh
 Synchronization method: Bluetooth
 Resolution: 390x450
 Display: 1.85 inch AMOLED
 Battery life: about 5-7 days
 Working temperature: -10°C~50°C
 Compatible system: IOS 12.0 or above, Android 6.0 or above

! Please read the instructions before use

- The watch has a water resistance rating of IP68. It can be used normally in daily life such as washing hands, raining, etc. Do not put the watch in hot water or in the shower, do not perform underwater pressing operations or deep diving. Waterproof effectiveness may reduce with daily wear.
- immersion in seawater or salty water, as it may cause corrosion and will not be covered under warranty. Product collisions, drops, or any visible signs of impact, including screen fractures, are not covered within the warranty scope. Do not disassemble the product or replace the battery without authorization.
- Charge the battery for two hours before use. Please avoid overcharging at 100% for an extended time. Please use the charger with an input voltage of 5V/1A or 5V/2A and XINJI's original magnetic charging cable.
- This product is not a medical device and cannot be used for medical purposes or as basis for diagnosis of any medical condition. Detection results are provided for reference only. Please consult professional medical institutions if you feel unwell.
- Avoid touching the screen surface with sharp or sticky objects to avoid damage. Avoid dropping the product on the ground or being strongly impacted by other objects. Avoid exposing the watch to corrosive liquids to avoid damage to the watch.
- If the product fails, please contact the after-sales service department. The company reserves the right to change or modify all the information in the document without notice. Due to software upgrades, the functions may vary in specific software versions.
- Avoid exposing the product to corrosive liquids or prolonged

↓ APP download & login



OnWear Pro App download

- Get OnWear Pro app in the App Store on your iPhone.
 - Get OnWear Pro app in Google Play on your Android phone.
 - Or scan the QR code in the watch to download the APP (compatible: IOS12.0 or above /Android6.0 or above);
- After installing the APP, please register and log in according to the interface prompts, and turn on Bluetooth at the same time;
- In the Device interface of OnWear Pro app, select the Bluetooth name: "XINJI C1 PLUS" for binding, and the watch can be used normally.

☞ Method of operation



From the home screen, swipe up from the bottom of the screen to enter the information list interface.



From the home screen, swipe down from the top of the screen to enter the shortcut interface.




From the home screen, swipe left from the right of the screen to enter the interface of steps, heart rate, sleep and other interfaces.



From the home screen, swipe right from the left of the screen to enter the menu list.


☞ Activity data



Swipe the touch screen from the right to the left, enter the sports data interface, and check the data of the day: the number of steps, distance, calories.



Turn on notification reminder and call reminder in the app, and information received by the mobile phone will be pushed to the smart watch synchronously. The watch can store multiple pieces of information.



Turn on Weather Push in the app, and the weather will be automatically synchronized to the watch.

☞ Phone




After the watch is connected to the mobile APP, find the frequently used contacts in the settings, and add contacts as required.



After connecting the APP, match the watch Bluetooth with the mobile phone, the Bluetooth display connection state, you can call from the watch.




Open the AOD clock in the watch settings and select digital clock or analog clock. The watch will continue to show the corresponding clock interface while it is asleep.



Heart rate monitoring

The measurement starts after the green indicator light at the bottom is on, and is completed after the vibration occurs in about 30~60s. The measurement is based on PPG technology.



Blood oxygen monitoring

The measurement starts after the red indicator light at the bottom is on, and is completed after the vibration occurs in about 30~60s. The measurement is based on PPG technology.



Sleep monitoring

It records and shows your sleep status that day. The data is updated every day and synchronized to the APP in the same time.



Sport mode

Get active your way by choosing your favorite workout modes, including hiking, running, climbing, cycling, basketball, yoga and elliptical and so on.



Meditation

Select the corresponding time, and follow the prompts on the watch until it is completed.



Women's health

Set your gender to female in the app and add information about the menstrual period. You can set up a period reminder with app.



Alarm clock

Find the alarm function in the list and add alarm clock according to the corresponding settings.



Stopwatch

Click the triangle icon to start and click again to pause (the left icon means resetting).



Timer

Count down from a specified time with the timer, and it ends with the vibration reminder.



Music

Turn on notification reminder in the app and open the music player on the watch to control music playback.



Watch face

Long press the home screen to switch watch faces. You can install hundreds of different watch faces on your watch through the app, or customize your favorite picture as a watch face.



Menu style

Select a menu style in watch settings. The menu supports list mode and smart mode.



Power on/off

Long press button for 3s to power on. The watch will automatically power on when it is charging. Choose 'Power Off' in the watch setting and click 'V' icon to shutdown.



System info

View the Bluetooth name, Mac address, Firmware version number and other information of the watch.



Reset

All personal data will be removed if you confirm to restore factory settings.

Warranty card

Customer information		Seller information	
Name		Name	
Add.		Add.	
E-mail		Purchase Date	
P.C.		Product model	
Tel		Invoice number	
Date	Malfunction		Process result